PRO6500 Portable Generator
Illustrated Parts List
Model 030336-0

Briggs & Stratton Power Products GROUP, LLC
Jefferson, Wisconsin, U.S.A.

IPL No. 311745 Rev B (01/11/2010)

Exploded View - Main Unit



Copyright © 2010 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form without the express written permission of Briggs & Stratton Power Products Group, LLC.

Parts List - Main Unit

Item	Part #	Description
1	B204631GS	CRADLE (Includes Items 20 & 31)
2	194218GS	MOUNT-VIBRATION
3	B92531GS	SUPPORT-ENGINE
4	190220GS	ADAPTER-ENGINE
5	*	NUT-HEX, M8-1.25
6	NSP	ALTERNATOR (see page 5)
7	B190723GS	SUPPORT-ENGINE
8	96796GS	WASHER
9	194219GS	MOUNT-VIBRATION
10	190274DGS	SCREW
11	187365JGS	SCREW
13	*	HHCS-M8 x 1.25 x 45
14	92532GS	BRACKET
15	710250	GASKET
16	*	HHCS-M6- 1.0 x 12
17	B4206GS	MUFFLER
18	67989GS	NUT
19	83083GS	SCREEN
20	B4986GS	DECAL
21	194153GS	MOUNT-VIBRATION
22	87680GS	NUT
23	*	HHCS-M6-1.0 x 40
24	194390GS	HEATSHIELD
25	191190GS	CAP
26	74908GS	TAPTITE
27	*	WASHER-5/16 - M8, LOCK
28	*	HHCS-M8-1.25 x 25
29	*	HHCS-5/16-18 x 3/4
30	204717GS	DECAL
31	200310GS	DECAL
32	204718GS	DECAL
33	193157GS	HARNESS-WIRING
34	195422GS	COVER-REAR BEARING

Item	**Part #**	**Description**
35	791745	KIT-FUEL HOSE (cut to fit)
36	*	WASHER-EXT #10, SHAKEPROOF
37	B2153GS	SCREW
38	192376GS	SCREW
40	*	HHS, 5/16-18 x 1
41	193272GS	VALVE-FUEL
42	193588GS	SPACER
43	B1797GS	CLIP-TREE
44	196035GS	TANK-FUEL
45	189135GS	CAP-FUEL
48	195373GS	WIRE
50	188333GS	DECAL
51	194984GS	DECAL
52	94480GS	DECAL
53	192724GS	GAUGE
54	194448GS	INSULATION
55	197797GS	DECAL
56	202997GS	DECAL
58	202531GS	PANEL-CONTROL
60	208564GS	HEATSHIELD
99	189759GS	KIT-FUEL VALVE REPAIR
900	§	ENGINE

Parts Not Illustrated

	204728GS	MANUAL-OPERATOR'S
	43438GS	PLUG-120/240V TL30A
	BB3061BGS	OIL
	65787GS	CABLE-BTTRY CHARGE
	100523GS	PLUG-125V TL30A

* - Items without part numbers are common fasteners and are available at your local hardware store.

§ - Contact Engine Manufacturer

Exploded View & Parts List - Control Panel



Item	Part #	Description
1	B192833GS	PANEL-CONTROL
2	B192836GS	BOX-CONTROL PANEL
3	*	WASHER-FLAT, #10 - M5
4	*	LOCKWASHER-M5
5	*	PPHMS-M5 - 0.8 x 12
6	*	WASHER-M6 - 1/4, INT. SHAKEPROOF
7	82538GS	SWITCH-ON/OFF
8	90418GS	OUTLET-12VDC
9	202602GS	METER-HOUR
10	*	LOCKWASHER-M3
11	*	NUT-M3 - 0.5
12	*	PHMS-M3 - 0.5 x 10
13	22694GS	CONNECTOR
14	87962GS	BREAKER-CIRCUIT 10A
15	84028GS	TRANSFORMER
16	64525GS	STANDOFF
17	193362GS	BOARD-IDLE CONTROL
18	*	PHTS-#6-32 x 3/8

Item	Part #	Description
19	193077GS	STRIP-TERMINAL
20	*	LOCKWASHER-M4
21	*	PPHMS-M5 - 0.8 x 20
22	*	NUT-M4 - 0.7
23	*	WASHER-FLAT, M4
24	192931GS	BRACKET
25	*	WASHER-SHAKEPROOF, INT. #8
26	192828DGS	BREAKER-CIRCUIT 30A
27	68868GS	OUTLET-120V-TL30A
28	43437GS	OUTLET-120/240V-30A
29	68759GS	OUTLET-120V 20A
30	193036GS	HARNESS-WIRING
31	193095GS	BLOCK-TERMINAL
32	202394GS	BREAKER-CIRCUIT 20A

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Parts List - Alternator



Item	Part #	Description
1	209599GS	ADAPTER-ALTERNATOR
2	192919GS	ROTOR
3	192920AGS	STATOR
4	186060GS	CARRIER-BEARING
5	86308HGS	BOLT
6	66386GS	ASSY-BRUSH
7	66849GS	TAPTITE
8	22694GS	CONNECTOR
9	81917GS	PIN
10	193428AGS	WIRE
11	65791GS	BEARING
13	192403XGS	WIRE
14	205858GS	REGULATOR-VOLTAGE
15	65795GS	RECTIFIER-BATTRY CHRG
16	66849AGS	TAPTITE

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Parts List - Wheel Kit



Item	Part #	Description
1	203273GS	WHEEL
2	*	WASHER-5/8
3	208975GS	AXLE
4	191265GS	E-RING
5	205135GS	BRAKE
6	*	SCREW-1/4-20 x 3/8
7	B193200GS	HANDLE
	198669GS	GRIP
8	*	WASHER-FLAT 5/16 - M8
9	*	NUT- M8 - 1.25, NYLOK
10	*	HHCS-M8 - 1.25 x 45
11	*	WASHER-1.2 x 0.346 x 0.03, NYLON
12	B4135GS	PIN

Items Not Illustrated

	205183GS	KIT-HARDWARE, WHEEL

* - Items without part numbers are common fasteners and are available at local hardware stores.